



Item No.	Description	No. Required Per Tester
1	W-125 Maincase - Portable Meter Tester	1
2	W-350 Flow Straightener	1
3	W-125 RER Measuring Chamber - with RER Register	1
4	W-350 Main Flange Gasket	1
5	W-125 RER Register Assembly - Replacement	1
6	5/8" SR Register Gasket	1
7	Register O-Ring	1
8	Register Jam Nut	1
9	Main Flange Capscrew 3/8" - 16 x 1"	10
10	End Plate	1
11	End Plate Capscrew 5/8" - 11 x 4"	4
12	2" Butterfly Valve	1
13	Bumper Foot, Rubber-Steel Core	3
14	2" Brass Closed Nipple	1
15	2" NPT x 2 1/2" NST Hex Coupling Adapter	1
16	Swivel Coupling Assembly - 2 1/2" NST Female	1
17	SRII RER Register Assembly - Replacement	1
18	Plastic Zip Tie	1
19	3/4" Bent Connection, Bronze	1
20	3/4" Union Nut, Bronze	2
21	3/4" Connection Gasket	2

Item No.	Description	No. Required Per Tester
22	5/8" x 3/4" SRII Meter Assembly with RER Register	1
23	Pressure Gage	1
24	3/4" x 1/4" Adapter, Bronze	1
25	1/4" Closed Nipple, Brass	1
26	1/4" Ball Valve	1
27	1/4" Brass Nipple	1
28	3/4" x 1/4" Hex Reducing Bushing	1
29	3/4" Hose Coupling, Brass	1
30	Reset Button - Replacement for all RER's	1
31	Screw for Reset Button	1
32	Lock Washer for Reset Button	1
33	Cover, Reset Button, Clear Plastic with Hole	1
34	Screen - for 2 1/2" Swivel Coupling	1
35	Clip Ring, to Retain #34	1
36	Adapter, Test Nipples to 2 1/2" Fire Hose (Not Shown)	1
37	Test Nipple, 1" Pipe - Use with #36 (Not Shown)	1
38	Test Nipple, 1 1/2" Pipe - Use with #36 (Not Shown)	1
39	Test Nipple, 2" Pipe - Use with #36 (Not Shown)	1
40	Spanner Wrench, For Hose Couplings (Not Shown)	1
41	Test Ring, for Direct Read Registers (Not Shown)	1
42	Test Ring, for GTR Registers (Not Shown)	1
43	Coupling Gasket	1

AUTHORIZED SENSUS DISTRIBUTOR